

Common Keyboard Map

for 34-Key PM450

Booting Procedures

Boot Type	Procedure
Warm Boot	Hold Power 3 sec
Cold Boot	Hold Power 8 sec

Local Terminal Functions

Local Function	Key Sequence
Program Information	N/A
Diagnostics	N/A
Keyclicks On/Off	N/A
Quiet Mode On/Off	N/A
Terminal Configuration	N/A
Host Profiles	N/A
Message Recall	N/A
Free Cursor Mode	N/A
Close Session	N/A
Previous Session	N/A
Next Session	N/A
Caps Lock	N/A
View Mode On/Off	N/A
Scroll Left	N/A
Scroll Right	N/A
Scroll Up	N/A
Scroll Down	N/A
Display Backlight On/Off	N/A
Keypad Backlight On/Off	N/A

Common Keyboard Map

for 34-Key PM450

5250 Emulation Keys

5250 Key	Key Sequence
Attention	N/A
Backspace	<BKSP>
Back Tab	N/A
Clear	N/A
Delete	N/A
Dup	N/A
Enter	N/A
Erase Input	N/A
Field Exit	<Ent>
Field Minus	N/A
Help	N/A
Home	<Blue><7>
Insert	N/A
Print	N/A
Reset	<Blue><Tab>
Roll Up	<Blue><H>
Roll Down	<Blue><R>
System Request	N/A
Tab	<TAB>
Left Arrow	<Left Arrow>
Right Arrow	<Right Arrow>
Up Arrow	<Up Arrow>
Down Arrow	<Down Arrow>

5250 Key	Key Sequence
F1	<F1>
F2	<F2>
F3	<F3>
F4	<F4>
F5	<Blue><F1>
F6	<Blue><F2>
F7	<Blue><F3>
F8	<Blue><F4>
F9	<F9>
F10	<F10>
F11	<F11>
F12	<F12>
F13	<Blue><F9>
F14	<Blue><F10>
F15	<Blue><F11>
F16	<Blue><F12>
F17	N/A
F18	N/A
F19	N/A
F20	N/A
F21	N/A
F22	N/A
F23	N/A
F24	N/A

Common Keyboard Map

for 34-Key PM450

3270 Emulation Keys

3270 Key	Key Sequence
Attention	N/A
Backspace	<BKSP>
Back Tab	N/A
Clear	<Blue><Tab>
Clear EOF	N/A
Delete	
Dup	<Blue><9>
Enter	<Enter>
Erase Input	N/A
Field Mark	N/A
Home	N/A
Insert	N/A
New Line	N/A
Reset	N/A
System Request	N/A
Tab	<TAB>
Left Arrow	<Left Arrow>
Right Arrow	<Right Arrow>
Up Arrow	<Up Arrow>
Down Arrow	<Down Arrow>
PA1	N/A
PA2	N/A
PA3	N/A

3270 Key	Key Sequence
F1	<F1>
F2	<F2>
F3	<F3>
F4	<F4>
F5	<Blue><F1>
F6	<Blue><F2>
F7	<Blue><F3>
F8	<Blue><F4>
F9	<F9>
F10	<F10>
F11	<F11>
F12	<F12>
F13	<Blue><F9>
F14	<Blue><F10>
F15	<Blue><F11>
F16	<Blue><F12>
F17	N/A
F18	N/A
F19	N/A
F20	N/A
F21	N/A
F22	N/A
F23	N/A
F24	N/A

Common Keyboard Map

for 34-Key PM450

VT-100 Emulation Keys

VT-100 Key	Key Sequence
Return	<Ent>
Backspace	<BKSP>
Tab	<TAB>
Up Arrow	<Up Arrow>
Left Arrow	<Left Arrow>
ESC	<Blue><Tab>
BS	N/A
LF	N/A
Hard Terminal Reset	N/A

VT-100 Key	Key Sequence
Enter	<Ent>
Backspace(Delete)	N/A
Backtab	N/A
Down Arrow	<Down Arrow>
Right Arrow	<Right Arrow>
PF1	<F1>
PF2	<F2>
PF3	<F3>
PF4	<F4>

VT-220 Emulation Keys

VT-220 Key	Key Sequence
Return	<Ent>
Backspace	<BKSP>
Tab	<TAB>
Up Arrow	<Up Arrow>
Left Arrow	<Left Arrow>
Hard Terminal Reset	N/A
Find	N/A
Insert Here	N/A
Prev Screen	N/A
PF1	<F1>
PF2	<F2>
PF3	<F3>
PF4	<F4>
BREAK ¹	<Blue><F1>
F6	<Blue><F2>
F7	<Blue><F3>
F8	<Blue><F4>
F9	<F9>
F10	<F10>

VT-220 Key	Key Sequence
Enter	<Ent>
Backspace(Delete)	N/A
Backtab	N/A
Down Arrow	<Down Arrow>
Right Arrow	<Right Arrow>
Soft Terminal Reset	N/A
Select	N/A
Remove	N/A
Next Screen	N/A
F11	<F11>
F12	<F12>
F13	<Blue><F9>
F14	<Blue><F10>
F15/Help	<Blue><F11>
F16/Do	<Blue><F12>
F17	N/A
F18	N/A
F19	N/A
F20	N/A

¹ The BREAK key is currently not available.

Common Keyboard Map

for 34-Key PM450

5250/3270/VT Character Map

Char	Key Sequence
Space	<SP>
!	<!>
“	N/A
#	<#>
\$	N/A
%	N/A
&	N/A
'	N/A
(	N/A
)	N/A
*	<*>
+	N/A
,	<,>
-	N/A
.	<.>
/	N/A
0	*<0>
1	*<1>
2	*<2>
3	*<3>
4	*<4>
5	*<5>
6	*<6>
7	*<7>
8	*<8>
9	*<9>
:	N/A
;	N/A
<	N/A
=	N/A
>	N/A
?	<?>
@	<@>

Char	Key Sequence
A	*<A>
B	*
C	*<C>
D	*<D>
E	*<E>
F	*<F>
G	*<G>
H	*<H>
I	*<I>
J	*<J>
K	*<K>
L	*<L>
M	*<M>
N	*<N>
O	*<O>
P	*<P>
Q	*<Q>
R	*<R>
S	*<S>
T	*<T>
U	*<U>
V	*<V>
W	*<W>
X	*<X>
Y	*<Y>
Z	*<Z>
[	N/A
\	N/A
]	N/A
^	N/A
_	N/A
`	N/A

Char	Key Sequence
a	*<A>
b	*
c	*<C>
d	*<D>
e	*<E>
f	*<F>
g	*<G>
h	*<H>
i	*<I>
j	*<J>
k	*<K>
l	*<L>
m	*<M>
n	*<N>
o	*<O>
p	*<P>
q	*<Q>
r	*<R>
s	*<S>
t	*<T>
u	*<U>
v	*<V>
w	*<W>
x	*<X>
y	*<Y>
z	*<Z>
{	N/A
	N/A
}	N/A
~	N/A

*The keypad defaults to numeric mode. Use the YELLOW key to toggle between numeric and alpha modes. Pressing the YELLOW key once locks the keypad in numeric mode, alpha mode (lowercase), or alpha mode (uppercase).

Common Keyboard Map

for 34-Key PM450

Char	Key Sequence
^@	N/A
^A	N/A
^B	N/A
^C	N/A
^D	N/A
^E	N/A
^F	N/A
^G	N/A
^H	N/A
^I	N/A
^J	N/A
^K	N/A
^L	N/A
^M	N/A
^N	N/A
^O	N/A
^P	N/A
^Q	N/A
^R	N/A
^S	N/A
^T	N/A
^U	N/A
^V	N/A
^W	N/A
^X	N/A
^Y	N/A
^Z	N/A
ESC	<Blue><Tab>
^\	N/A
^]	N/A
^^	N/A
^_	N/A