

VT/HP Keyboard Map

for Intermec 700c Alphanumeric Keyboard (38 Key)

Booting Procedures

Boot Type	Procedure
Suspend	Press and release Power
Warm Boot	Hold Power for 10 seconds
Cold Boot	Remove Battery and press button in battery compartment

Local Terminal Functions

Local Function	Key Sequence
Program Information	N/A
Keyclicks On/Off	N/A
Quiet Mode	N/A
Terminal Configuration	N/A
Host Configuration	N/A
VT/HP Terminal Setup	N/A
Close Session	N/A
Previous Session	N/A
Next Session	N/A
Caps Lock	<Orange><Cap>
View Mode On/Off	N/A
Scroll Left	<Left Arrow>
Scroll Right	<Right Arrow>
Scroll Up	<Up Arrow>
Scroll Down	<Down Arrow>

VT/HP Keyboard Map

for Intermecc 700c Alphanumeric Keyboard (38 Key)

VT-100 Emulation Keys

VT-100 Key	Key Sequence
Return	<Enter>
Backspace	<BkSp>
Tab	<Orange><Right Arrow>
Up Arrow	<Up Arrow>
Left Arrow	<Left Arrow>
ESC	<Esc>
BS	<BkSp>
LF	<Orange><Esc>
Hard Terminal Reset	N/A

VT-100 Key	Key Sequence
Enter	<Enter>
Backspace(Delete)	N/A
Backtab	<Orange><Left Arrow>
Down Arrow	<Down Arrow>
Right Arrow	<Right Arrow>
PF1	N/A
PF2	N/A
PF3	N/A
PF4	N/A

VT-220 Emulation Keys

VT-220 Key	Key Sequence
Return	<Enter>
Backspace	<BkSp>
Tab	<Orange><Right Arrow>
Up Arrow	<Up Arrow>
Left Arrow	<Left Arrow>
Hard Terminal Reset	N/A
Find	N/A
Insert Here	N/A
Prev Screen	<Orange><J>
PF1	N/A
PF2	N/A
PF3	N/A
PF4	N/A
BREAK ¹	N/A
F6	N/A
F7	N/A
F8	N/A
F9	N/A
F10	N/A

VT-220 Key	Key Sequence
Enter	<Enter>
Backspace(Delete)	N/A
Backtab	<Orange><Left Arrow>
Down Arrow	<Down Arrow>
Right Arrow	<Right Arrow>
Soft Terminal Reset	N/A
Select	N/A
Remove	N/A
Next Screen	<Orange><P>
F11	N/A
F12	N/A
F13	N/A
F14	N/A
F15/Help	N/A
F16/Do	N/A
F17	N/A
F18	N/A
F19	N/A
F20	N/A

VT/HP Keyboard Map

for Intermecc 700c Alphanumeric Keyboard (38 Key)

HP Emulation Keys²

HP Key	Key Sequence
Return	<Enter>
Backspace	<BkSp>
Tab	<Orange><Right Arrow>
Up Arrow	<Up Arrow>
Left Arrow	<Left Arrow>
Insert Line	N/A
Insert Char	N/A
Hard Terminal Reset	N/A
Prev	<Orange><J>
Clear Line	N/A
Insert Char with wrap	N/A
Scroll Down	N/A
F1	N/A
F2	N/A
F3	N/A
F4	N/A
User Key Menu	N/A

HP Key	Key Sequence
Enter	<Enter>
Backspace(Delete)	N/A
Backtab	<Orange><Left Arrow>
Down Arrow	<Down Arrow>
Right Arrow	<Right Arrow>
Delete Line	N/A
Delete Char	N/A
Soft Terminal Reset	N/A
Next	<Orange><P>
Clear Display	N/A
Delete Char with wrap	N/A
Scroll Up	N/A
F5	N/A
F6	N/A
F7	N/A
F8	N/A
System Modes Menu	N/A

² The BREAK and STOP keys are currently not available.

VT/HP Keyboard Map

for Intermecc 700c Alphanumeric Keyboard (38 Key)

VT/HP Character Map

Char	Key Sequence
^@	N/A
^A	N/A
^B	N/A
^C	N/A
^D	N/A
^E	N/A
^F	N/A
^G	N/A
^H	N/A
^I	N/A
^J	N/A
^K	N/A
^L	N/A
^M	N/A
^N	N/A
^O	N/A
^P	N/A
^Q	N/A
^R	N/A
^S	N/A
^T	N/A
^U	N/A
^V	N/A
^W	N/A
^X	N/A
^Y	N/A
^Z	N/A
ESC	<Esc>
^\	N/A
^]	N/A
^^	N/A
^_	N/A
Space	<Space>
!	N/A
“	N/A
#	N/A
\$	N/A
%	N/A
&	N/A
'	N/A
(	N/A
)	N/A
*	* <G>

Char	Key Sequence
+	*<R>
,	*<Q>
-	*<L>
.	*<V>
/	*<H>
0	<0>
1	<1>
2	<2>
3	<3>
4	<4>
5	<5>
6	<6>
7	<7>
8	<8>
9	<9>
:	N/A
;	N/A
<	N/A
=	*<F>
>	N/A
?	N/A
@	*<K>
A	<Cap> <A>
B	<Cap>
C	<Cap> <C>
D	<Cap> <D>
E	<Cap> <E>
F	<Cap> <F>
G	<Cap> <G>
H	<Cap> <H>
I	<Cap> <I>
J	<Cap> <J>
K	<Cap> <K>
L	<Cap> <L>
M	<Cap> <M>
N	<Cap> <N>
O	<Cap> <O>
P	<Cap> <P>
Q	<Cap> <Q>
R	<Cap> <R>
S	<Cap> <S>
T	<Cap> <T>
U	<Cap> <U>

Char	Key Sequence
V	<Cap> <V>
W	<Cap> <W>
X	<Cap> <X>
Y	<Cap> <Y>
Z	<Cap> <Z>
[	N/A
\	N/A
]	N/A
^	N/A
_	N/A
`	N/A
a	<A>
b	
c	<C>
d	<D>
e	<E>
f	<F>
g	<G>
h	<H>
i	<I>
j	<J>
k	<K>
l	<L>
m	<M>
n	<N>
o	<O>
p	<P>
q	<Q>
r	<R>
s	<S>
t	<T>
u	<U>
v	<V>
w	<W>
x	<X>
y	<Y>
z	<Z>
{	N/A
	N/A
}	N/A
~	N/A

* Alpha Mode is off.